

REMOTE CONTROL INSTRUCTIONS

1. Basics

- 1). Be careful with the remote control and do not drop it as the remote control is a precision-fabricated device.
- 2). If you decide to use the remote control for starting, you cannot use the start switch on the generator, or else you may blow the fuse out.
- 3). If the distance for the remote control reduces and or if the light is dark, you should replace the battery in the remote control(23A, 12V).

2. Operation procedures

- 1). Remote control starting(**DO NOT USE THE STARTING SWITCH**). The generator will automatically start when you press the "1" key twice. If starting in cold weather, please repeat this procedure several times. **NOTE:** If the battery power is low, the remote control feature will not work properly.
- 2). If the remote control was chosen to start the generator, the remote control should be chosen to stop the unit. To stop the unit, press the number "2" key and the generator will automatically stop.

3. Description of keys

- 1). Remote control start.
- 2). Remote control stop.

